


SINGER
188K

List of Parts—Machine No. 188K

ATTACHMENT SET 86505

732(802)	Guide Screw
25878	Cloth Guide
36554	Presser Foot
36837	Feller Foot
36838	Hemmer Foot
36839	Hemmer Foot
36840	Gathering Foot
55623	Bobbin (5)
120861	Oil 3 oz.
161294	Screwdriver (1G)
161295	Screwdriver (SM)
2254(16x231)	Needles (6)



This diagram illustrates the exploded view of a sewing machine, showing the main body and various components. The central part of the diagram shows the main body of the sewing machine, including the motor, hand, and foot. Surrounding this central body are numerous numbered parts and sub-assemblies, each labeled with a unique identifier. These parts include various gears, levers, and structural components. The diagram is organized into several distinct sections, each containing a group of related parts. For example, the top left section shows the motor and hand assembly, while the bottom right section shows the foot and needle assembly. The parts are arranged in a way that shows their relative positions and how they fit together to form the complete sewing machine. The diagram is a technical drawing, likely used for manufacturing or repair purposes.